V-BUSTER -Air Purifying with Eye Care Lighting

Model: VB-060624-128A - Air Purifying Specifications

Medical areas: Hospital, Clinic, Postnatal Care Center,

Nursery Room, Rehabilitation Center.

Anti- Viruses & Bacteria x Formaldehyde x PM 0.3 x PM 2.5

Super Prevent Indoor Infections from Air Pollutions

Safely Caring x Easy Working x Comfortable Recuperating.

School areas: Kindergarten, School, Tutorial Class Room.

Anti- Viruses & Bacteria x Formaldehyde x PM 0.3 x PM 2.5

Super Prevent Indoor Infections from Air Pollutions

Safely Caring x Easy Working x Comfortable Recuperating.

VIP areas: VIP Meeting Room, CEO Office, VIP Lounges.

Sports areas: Gym, Sports Center.

High-Standard areas: Pharmaceutical Factory, Semiconductor Manufacturing Factory.

Anti- Viruses & Bacteria x Formaldehyde x PM2.5

Super Prevent Indoor Infections from Air Pollutions


Easy Working x Comfortable Communicating x Safely Exercising

Preventive Medical Theory

Specially Designed for Clinics, Schools, VIP Spaces & Home Care

Active Decomposes H1N1 x Enterovirus x Bacteria Blocking Formaldehyde x PM0.3 x PM2.5 x Fungus x Bad Smelling


24hours Air Purification x Super Prevent Indoor Infections Safely Caring x Easy Working x Healthy Growing x Comfortable Recuperating



- 1. Interfering the synthesis of the cell wall & Damaging the cell membranes.
- 2. Inhibiting the protein synthesis & Interfering the nucleic acid synthesis.
- 3. Inhibiting reproduction ability of bacterium, Destroying metabolism & Decomposing the structure of cell membrane.
- 4. Viruses and bacteria are completely decomposed.

Features of TTA(NTDA) (Nano TiO2 Doped with Ag+)

- Patents: Germany, U.S.A., Japan, China & Taiwan Province.
- Tested & Certified: SGS & USA-Microbac Laboratories etc.
- 99% Active Decomposes Viruses & Bacteria without Causing Dirt Accumulation.
- Decomposed the Harmful Gases and Converted Into Non-toxic & Harmless Substances.
- Anti Formaldehyde \ PM2.5 \ TVOC & Fungus.
- Break down Bio-Waste into Hydrophilia and Carbon Dioxide.
- Pass Non-Toxic Testing: the Stem Cells of Adults & Newborns.
- · Pass Non-Toxic Testing: Skin & Oral.
- · Long-term effectiveness; even when the light is turned off.




V-BUSTER - Air Purifying with Eye Care Lighting

Model: VB-060624-128A - Lighting Specifications

Features:

- 1. Professional LED Eye-care Lighting
- 2. Flicking Free Lighting Design
- 3.No Glare UGR < 19
- 4. Dimmable 4 Step Memory mode (100%, 60%, 30%, 0%)
- 5. Edge-lite LED panels for office & commercial application.
- 6. Uniform light emission by using optical Polycarbonate.
- 7. High light efficiency 100lm/W (other option :120/W)
- 8.Emergency option available: compatible in use with most emergency battery brands & comply with part A11 of FSD regulation PPA104
- 9. Suitable for installation in Recessed Ceilings.



Model:VB-060624-128-A order Code :1718.223

Standard

Voltage (V)

Dimension	600*600*90mm

Beam Angle: 110 degree

CRI >80Ra

UGR > 19

Flicker Free

Luminous Efficacy 120lm/W

Power Factor > 0.90

Power (W) 24.0W - 100% (2880lm)

14.4W - 60% (1728lm) 7.2W - 30% (864lm)

AC90-264V

Cover Material Plastic-PC VO

Color Temperature 6000K / 5000K / 4000K


Insulation CLASS 1


Protection IP 20

Operating temperature 0~35℃


Operating Humidity 25-80%RH

Life Time 50,000(H)









Model: VB-060624-128A - Lighting accessories


Understanding Main Appliance





TTA (NTDA) Full Efficiency Entry Filter(with Cover) X 2






Remote Control(with Holder) X 1 AAA Battery X 2



Safety Sling (with Hook) X1 Note: Make sure that installing safety sling correctly(see P4-P5) to ensure the best security.



This Manual X 1



Remote Control Functions



[Swithch On/Off] button



[Circulation] button

Press the button once to trun off the light, but keep the functions of circulation and purification. Simply press the button again to trun on the light.



[Dimming (Brightness)] button

Press and hold the button to choose the brightness you perfer.



[Dimming (Dimness)] button

Press and hold the button to choose the dimness you perfer.



[Fan Speed (Up)] button

Press and hold the button to increase and to choose the fan speed from 0%, 30%, 60% to 100% -



[Fan Speed (Down)] button

Press and hold the button to decrease and to choose the fan speed from 100%, 60%, 30% to 0% ·



[Maintenance Mode] button

Must be cooperated with (to activate the function.





[Set Up] (Protection Lock) button

